



Setting	Description
G1 SELECT PROGRAM	<b>Operation</b> Selection of the preset time temperature programs (see Select program) Factory setting: <b>1</b> - Program 1 Select program <b>1, 2</b> or <b>3</b> : <b>+/-</b>
G2 EVENT SETTING	Adjusting a preset time temperature program Set weekday, temperature, event: <b>+/-</b> , press <b>OK</b> to confirm (see Adjusting program)
G3 CLOCK SETTING	Setting the date and time Set <b>YEAR, MONTH, DAY, HOUR, MINUTE</b> : <b>+/-</b> , press <b>OK</b> to confirm
G4 OFF HEATING PERMANENT	Switch off the controller, no temperature, frost protection is active, if set by the electrician. Select: <b>YES/NO</b> - heating off/on: <b>+/-</b> , press <b>OK</b> to confirm Display of function (16): <b>OFF</b> Switch on controller again: Select any function via the menu or keep <b>Menu/+</b> pressed down for 10 s
G5 SUMMER/WINTER TIME CHANGE	Select whether or not the summer/winter time change should be carried out automatically. Factory setting: <b>YES</b> - Switchover on Select: <b>YES/NO</b> : <b>+/-</b> , press <b>OK</b> to confirm
G6 KEY LOCK	Protection of the controller against unauthorized operation If the key lock is active, no operation is possible Select: <b>YES</b> (key lock)/ <b>NO</b> : <b>+/-</b> , press <b>OK</b> to confirm Cancel key lock again: Press any push-button, when <b>CODE</b> is displayed set <b>93</b> using <b>+/-</b> and press <b>OK</b> to confirm
G7 TEMP LIMIT MIN/MAX TEMP	Set parameter of the lower and upper temperature for the controller Factory setting: <b>LOWER TEMP LIMIT = 5 °C, UPPER TEMP LIMIT = 30 °C</b> Set temperatures: <b>+/-</b> , press <b>OK</b> to confirm
G8 COST/HR OF ENERGY	Enter the estimated energy costs per hour for the room being controlled. The calculated consumption is displayed under <b>G9</b> . <b>i</b> If the energy costs counter should be used as operating hours counter, set value <b>COSTS/h</b> to <b>100</b> . Factory setting: <b>10</b> Set <b>COSTS/h</b> : <b>+/-</b> , press <b>OK</b> to confirm
G9 ENERGY-CONSUMPTION TO DATE	Display of the approximate calculated energy consumption/operating hours for <b>2 DAYS – WEEK – 30 DAYS – YEAR</b> . The current day until the display time is taken into account. Calculation: Duty cycle of the heating x <b>COSTS/h</b> Select time period for calculating the energy consumption: <b>+/-</b> Return to the menu: <b>OK</b> Resetting using <b>INSTALLER SETTINGS H9</b>
G10 SET TEMP TO READ	Setting whether the setpoint temperature should be displayed in the basic display instead of the current room temperature Work setting: <b>NO</b> – room temperature display Select: <b>YES/NO</b> : <b>+/-</b> , press <b>OK</b> to confirm
G11 ADJUST TEMP	Determining the correction value by which the measured temperature should be corrected for display and controller <b>i</b> Sensible adjustments: e.g. alignment with calibrated thermometers, compensation of installation heights and installation locations that are not optimum Factory setting: <b>0.0</b> - no correction Adjust correction value: <b>+/-</b> , press <b>OK</b> to confirm
G12 NUMBER FOR FLOOR TEMPERATURE	Only when using as floor temperature controller! Activating the display of the floor temperature as information number The display °C is hidden Factory setting: <b>NO</b> (normal temperature display) Select: <b>YES/NO</b> : <b>+/-</b> , press <b>OK</b> to confirm
G13 BACKLIGHT	Adjusting the display lighting: <b>SHORT</b> = on for a short time after pressing push-button, <b>OFF</b> = permanently off Factory setting: <b>SHORT</b> Set lighting behaviour: <b>+/-</b> , press <b>OK</b> to confirm
G14 LANGUAGE	Selection of the language for the display text in the display: <b>DEUTSCH, ENGLISH, NEDERLANDS, FRANCAIS</b> Select language: <b>+/-</b> , press <b>OK</b> to confirm
G15 INFO	Display of the controller type and controller version Return to menu: <b>OK</b>
G16 RESET USER SETTINGS ONLY	Resetting the user settings to factory settings <b>i</b> The counter <b>ENERGY-CONSUMPTION TO DATE</b> is not reset. The settings are reset via menu <b>H9</b> . Select: <b>YES</b> (Reset)/ <b>NO</b> : <b>+/-</b> , press <b>OK</b> to confirm

Table 2: Overview of the user settings and their selection

## Information for electricians

### Assembly and electrical connection

#### **DANGER!**

**Touching live parts can result in an electric shock.**

**An electric shock can lead to death.**

**Disconnect connecting cables before working on the device and cover all live parts in the area!**

#### Installation location

To enable optimum room temperature control using the internal sensor, the installation location selected should

- allow free air circulation
- not be located behind curtains, cupboards, shelves etc.
- not be exposed to direct sun light
- be free of draughts
- not be on external walls
- be approx. 1.5 m above the floor

#### Connecting and mounting the device




Figure 6: Connection diagram

- Remove operating unit from the insert.
- Strip a max of 8 mm from connecting cables.
- Connect controller according to connection diagram (Figure 6).
- Connect an external temperature sensor if necessary (see connecting external temperature sensor).




Figure 7: Mounting

- Align insert (7) in the connector socket and fix it into position with fastening screws (20). Mount the insert in such a way that the plastic tongue (19) acts as insulation for the fastening screw. (Figure 7)
- Mount the design frame (5) and fix it into position by attaching the operating unit (3).

## Connecting external temperature sensor

An external temperature sensor is required for the thermostat process of the floor thermostat and thermostat with limiter. It is advisable to lay the temperature sensor in a protective pipe so that it can be replaced later.

**i** The wire of the temperature sensor supplies mains voltage and can be extended to 50 m using suitable wires.

**i** To avoid signal disturbances, do not lay the wire of the temperature sensor together with mains cables.

■ Strip a maximum of 8 mm from the temperature sensor wire

■ Connect temperature sensor according to connection diagram (Figure 6, 18).




Figure 8: Terminal for connecting the temperature sensor

**i** When using flexible wire, insert and remove the wire release button (21) with an appropriate tool.

### Commissioning

#### **CAUTION!**

**Malfunction of the heating system with incorrect controller settings.**

**The heating system could get damaged. Only allow settings of the heating system to be carried out by a skilled specialist.**

#### Setting the heating type

When commissioning the controller, the heating type must be set.

The device is in the basic display.

- Press **Menu/+** (8) push-button.  
A help text is shown at the bottom of the display.
- Keep pressing the **+/-** push-button repeatedly until **INSTALLER SETTINGS** is displayed.
- Press **OK**.  
**CODE** is displayed and the code number **0** flashes.
- Select: code number using **7 +/-** and press **OK** to confirm  
**H 1** and the scrolled text of **APPLICATION** is displayed.
- Press **OK**.
- Set the desired temperature using **+/-** and press **OK** to confirm.
- i** **ROOM** is preset. When changing the heating type, all user and installer settings are reset to the factory settings.

#### Overview and selection of the settings

The settings menu is invoked (see Setting heating type). If **H1** and the scrolled text of **APPLICATION** is displayed, you can toggle between the possible settings menus using **+/-** (see Table 3).

Setting	Description
H1 APPLICATION	<b>Operation</b> Selecting between the thermostat processes according to heating type: - <b>ROOM</b> = Room thermostat - <b>FLOOR</b> = Floor thermostat - <b>LIMITER</b> = Room thermostat with limiter Factory settings: <b>ROOM</b> When used as a room thermostat, it is also possible to set whether an external temperature sensor ( <b>EXTERNAL SENSOR = YES</b> ) is connected. Selection of the heating type: <b>+/-</b> , press <b>OK</b> to confirm
H2 CONTROL MODE	Selection of the control type: - <b>PWM</b> (Pulse width modulation) with adjustment option for cycle time. Select short cycle time for fast heating systems and long cycle time for slow heating systems. Factory setting of cycle time: <b>10 min</b> The minimum switch on/off time is 10 % of the cycle time. - <b>ON/OFF</b> (on-off control) with the setting option of hysteresis and minimum switch on/off time of the relay Factory setting hysteresis: <b>OFF</b> Factory setting minimum switch on/off time: 10 min <b>i</b> If no hysteresis is set, the relay switches with the set minimum switch on/off time even in the case of very small temperature differences. Selection of controller, cycle time, hysteresis, switch on/off time: <b>+/-</b> , press <b>OK</b> to confirm
H3 MIN/MAX FLOOR-TEMP	Only when using as room thermostat with limiter. Setting the minimum and maximum floor temperature for the limit: - <b>LOWER LIMIT OF FLOOR TEMPERATURE</b> : The floor does not become colder than the temperature set here. Factory settings: <b>OFF</b> (no limit) - <b>UPPER LIMIT OF FLOOR TEMPERATURE</b> : The floor does not become colder than the temperature set here. Factory setting: <b>35 °C</b> Set temperatures: <b>+/-</b> , press <b>OK</b> to confirm <b>i</b> The lower temperature limit < 10 °C or the upper temperature limit > 40 °C must be set using <b>+/-</b> in order to deactivate the upper or lower limit with <b>OFF</b> . <b>OFF</b> is displayed.
H4 HEATING OR COOLING	Switchover of the controller to cooling mode/heating mode Cooling mode only when using as room thermostat and <b>H2 - CONTROL MODE = ON/OFF</b> In cooling mode: - Using the events and temperature of the heating mode - <b>H6 FROST PROTECTION = OFF</b> - <b>H7 OPTIMUM START = NO</b>
H5 VALVE PROTECTION	Protection of the valve against sticking after a longer absence of control The valve is opened daily at 10:00 for the time set here in minutes. Factory setting: <b>3 min</b> Set opening time: <b>+/-</b> , press <b>OK</b> to confirm
H6 FROST PROTECTION	Setting the frost protection mode and temperature When frost protection is activated, the heating is activated if the temperature falls below the set frost protection temperature Factory setting: <b>5 °C</b> <b>i</b> Frost protection mode only possible when controller is switched off. Set temperature: <b>+/-</b> , press <b>OK</b> to confirm <b>i</b> To deactivate the frost protection with <b>OFF</b> , set the temperature < 5 °C by pressing the push-button <b>-</b> . <b>OFF</b> is displayed.
H7 OPTIMUM START	This setting causes the setpoint temperature to be reached already at the start time. <b>AUTO_</b> is displayed in the required pre-heating time. Factory setting: <b>YES</b> Set <b>YES</b> (OPTIMUM START)/ <b>NO</b> : <b>+/-</b> , press <b>OK</b> to confirm
H8 VALVES NORMALLY OPEN	Switchover of the relay switching behaviour opened for using actuators currentless Factory setting: <b>NO</b> (deactivated) Select: <b>YES</b> (activated)/ <b>NO</b> : <b>+/-</b> , press <b>OK</b> to confirm
H9 ENERGY COUNTER RESET	Resetting the energy costs counter set under <b>G8/G9</b> to 0 Select <b>YES</b> (reset): <b>+/-</b> , press <b>OK</b> to confirm
H10 DISPLAY FLOOR TEMPERATURE	Only when using as room thermostat with limiter Display of the current floor temperature for service purposes ---
H11 RESET ALL	Resetting all installer and user settings carried out in the settings menu to the factory settings Select <b>YES</b> (reset): <b>+/-</b> , Press <b>OK</b> to confirm

Table 3: Overview of the installer settings and their selection

## Displaying device errors

Errors in the hardware configuration can be shown via the display. In this case, **ERR** and an additional error type are displayed as scrolled text.

Error type	Description
ERR	Measures for removal
ERR CONFIGURATION	Operating unit and insert do not match - Only use related components - Switch off voltage and switch on again
ERR COMMUNICATION	Communication between operating unit and insert interrupted - Remove operating unit and attach once again - Switch off voltage and switch on again
ERR EXT SENSOR	Failure/short circuit of the external temperature sensor - Replace temperature sensor Display range exceeded/fallen short of - ---

### Appendix

#### Specifications

Operating voltage	AC 230 V~
Rated frequency	50 Hz
Output	relay NO contact, potential-linked
Switching current	10 mA ... 10 (4)A, 230 V~
Power consumption	approx. 1.2 W
Rated impulse voltage	4 kV
Ball pressure test temperature	75 °C (± 2 °C)
Protection class	IP30
Protection Class (s. Safety instructions)	II
Operating temperature	0 ... 40 °C (without condensation)
Storage temperature	-20 ... 70 °C (without condensation)
Temperature-adjustment range	in 0.5 °C increments
Room thermostat (with limiter)	5 ... 30 °C
Floor thermostat	10 ... 40 °C
Temperature display	in 0.1 °C increments
Output signal	Pulse width modulation (PWM) or on-off control (On/Off)
PWM cycle time	adjustable
Hysteresis	adjustable (with on-off control)
Minimum event	10 min
Time deviation	< 4 min per year
Power reserve by means of lithium battery	approx. 10 years

#### Resistance/temperature table for remote sensor

Temperature [°C]	10	20	25	30	40	50
Resistor [kΩ]	66.8	41.3	33	26.3	17.0	11.3

## Troubleshooting

### It becomes warm too late

Cause 1: Programmed events or time do not match.

Adjust programming.

Cause 2: A summer/ wintertime changeover has taken place in the meantime (G5).

Adjust time.

Cause 3: Optimum Start H7 is deactivated or has not run long enough yet (a few days) to determine the optimum pre-heating time.

Select Optimum Start and give the controller time to adjust itself to the conditions of the controlling environment.

### It is not possible to enter any data

Cause: Key lock G6 is active.

Cancel key lock.

### The desired temperature cannot be set

Cause: Temperature limit G7 prevents the desired setting.

Reset temperature limit.

### Temperature display does not change

Cause: Display of the set temperature G10 is activated.

Activate display of the room temperature.

### Warranty

We reserve the right to make technical and formal changes to the product in the interest of technical progress.

Our products are under guarantee within the scope of the statutory provisions.

If you have a warranty claim, please contact the point of sale or ship the device postage free with a description of the fault to the appropriate regional representative.