



### Keys

- |         |   |
|---------|---|
| 1. Menu | Selection of operating mode   |
| Auto    | Mode of running according to the program selected                               |
| Prog    | New for programming mode  |
| Prog    | To modify an existing program   |
|         | Checking of the program   |
|         | Modification of time, date and selection of the winter/summer time change mode. |
|         | Holidays  |
| 2. +/-  | Navigation or setting of values   |
|         | In auto, mode, selection of overrides, waivers or random operation              |
| 3. OK   | To validate flashing information on display                                     |
| 4.      | To return to the previous step  |

You may return into auto mode at any moment using menu.  
If no action is taken for 1 min, the switch returns to auto mode.

### Major Characteristics

- Product delivered with current time and date set
- Automatic change of winter / summer time
- Programming key
  - For permanent waivers
  - For program copy or save
- Programming for day or group of days
- 56 program steps On, Off
- Impulses (1 sec to 30 min)\*
- Permanent overrides On or Off ( permanent light on)
- Temporary overrides On or Off ( flashing)
- Holiday mode : overrides On or Off between two dates\*
- Simulation of presence \*
- Display bar graph of daily profile
- Keyboard locking possible
- Programmable with power off
- Back lit display\*

\* Evolution models E or V only

### Connection Diagram

