

Overview symbols

KNX Touch Control





































	Order number	Product designation	Application programme	TP product Radio product
	7574 0101	KNX Touch Control	S7574 0101 	

Overview symbols

















1 – 24 Lighting					
1	Ceiling lamp On - coloured		13	Floor spotlight On - coloured	
2	Ceiling lamp On		14	Floor spotlight On	
3	Ceiling lamp Off		15	Floor spotlight Off	
4	Wall lamp On - coloured		16	Standard lamp On - coloured	
5	Wall lamp On		17	Standard lamp On	
6	Wall lamp Off		18	Standard lamp Off	
7	Spot On - coloured		19	Table lamp On -coloured	
8	Spot On		20	Table lamp On	
9	Spot Off		21	Table lamp Off	
10	Suspended ceiling lamp On - coloured		22	Light On - coloured	
11	Suspended ceiling lamp On		23	Light On	
12	Suspended ceiling lamp Off		24	Light Off	



























25 – 28 Rotary control					
25	Coloured ring heating		27	Coloured ring ventilation	
26	Coloured ring light		28	Coloured ring	










29 – 48 Drive					
29	Blind down		39	Garage door open	
30	Blind up		40	Garage door closed	
31	Roller shutter down		41	Door open	
32	Roller shutter up		42	Door closed	
33	Awning extended		43	Lock unlocked	
34	Awning retracted		44	Lock locked	
35	Window open		45	Roof window open	
36	Window closed		46	Roof window closed	
37	Sliding gate open		47	Light dome open	
38	Sliding gate closed		48	Light dome closed	
















49 – 85 Symbols (Operation)					
49	Zero	0	67	Settings	
50	One	1	68	On	
51	Two	2	69	Off	
52	Three	3	70	Standby	
53	Four	4	71	Switching time	
54	Five	5	72	Manual	
55	Six	6	73	Automatic	a
56	Seven	7	74	OK	OK
57	Eight	8	75	Dimming up	+
58	Nine	9	76	Dimming down	-
59	Navigate left	<	77	Bell	
60	Navigate right	>	78	Dustbin	
61	Navigate upward	^	79	Scene	
62	Navigate downward	v	80	Forced mode active	
63	Navigate back	↶	81	Forced mode inactive	
64	Navigate forward	↷	82	Forced mode OFF active	
65	Plus	+	83	Forced mode OFF inactive	
66	Minus	-	84	Forced mode ON active	
			85	Forced mode ON inactive	

86 – 125 Climate					
86	Heating element On - coloured		106	Present / Comfort	
87	Heating element On		107	Frost/heat protection - coloured	
88	Heating element Off		108	Frost/heat protection	
89	Underfloor heating - coloured		109	Party mode	
90	floor heating		110	Fan On	
91	Wall heating - coloured		111	Fan Off	
92	Wall heating		112	Fan level 1	
93	Ceiling heating - coloured		113	Fan level 2	
94	Ceiling heating		114	Fan level 3	
95	Floor cooling - coloured		115	Fan level 4	
96	Floor cooling		116	Fan level 5	
97	Wall cooling - coloured		117	Fan level 6	
98	Wall cooling		118	Heating - coloured	
99	Ceiling cooling - coloured		119	Heating	
100	Ceiling cooling		120	Heating plus	
101	Night lowering - active		121	Heating minus	
102	Night lowering		122	Cooling - coloured	
103	Absent - active		123	Cooling	
104	Absent		124	Cooling plus	
105	Present / Comfort - active		125	Cooling minus	

126 – 142 Sensors					
126	Sun		134	Humidity	
127	Rain		135	Outdoor Temperature	
128	Snowfall		136	Indoor Temperature	
129	Frost		137	Fountain	
130	Tank		138	Pond	
131	Pyranometer		139	Wind direction	
132	Humidity		140	Strong wind	
133	Earth moisture		141	Light wind	
			142	CO ₂	CO₂

143 – 168 Multimedia					
143	TVs		156	Socket outlet GB On	
144	Video projector		157	Socket outlet GB Off	
145	Screen		158	Music	
146	Socket outlet On		159	Play	
147	Socket outlet Off		160	Pause	
148	Socket outlet France 2pole On		161	Backward	
149	Socket outlet France 2pole Off		162	Forward	
150	Socket outlet France 3pole On		163	Stop	
151	Socket outlet France 3pole Off		164	Back	
152	Socket outlet Germany On		165	Forward	
153	Socket outlet Germany Off		166	Loudspeaker	
154	Socket outlet Switzerland On		167	Softer	
155	Socket outlet Switzerland Off		168	Louder	

169 – 177 Security					
169	Motion detector		174	Siren outside armed	
170	Siren		175	Siren armed	
171	Attention		176	Siren outside	
172	Open		177	Siren inside	
173	Siren inside armed				

178 – 193 House					
178	House		186	Housekeeping	
179	Dining room		187	Storage room	
180	Lounge		188	Laundry	
181	Kitchen		189	Toilet	
182	Child's room		190	Office	
183	Bathroom		191	Hallway	
184	Bedroom		192	Carport	
185	Dressing room		193	Garden	