






- (FR) Contact auxiliaire HZ022
- (GB) Auxiliary switch HZ022
- (DE) Hilfsschalter HZ022
- (IT) Contatto ausiliario HZ022
- (ES) Contacto auxiliare HZ022

- Notice d'instructions
- User instructions
- Montageanleitung
- Istruzioni di montaggio
- Instrucciones de uso


HA304, HA404, HA305, HA405, HA306, HA406,  
HA406N, HA307, HA407, HA308, HA408



HA304  
HA404  
HA305  
HA405  
HA306  
HA406




HA406N  
HA307  
HA407  
HA308  
HA408




HA304-HA404-HA305  
HA405-HA306-HA406


①




②




③



④




⑤




HA406N-HA307-HA407  
HA308-HA408


①




②



③



④



⑤

