



- (DE) Montageanleitung
- (FR) Notice d'instructions
- (GB) Mounting instructions
- (NL) Montage instructie
- (DK) Monteringsvejledning
- (FI) Asennusohje
- (NO) Montasjeanvisning
- (SE) Monterings instruktioner
- (IT) Istruzioni di montaggio
- (ES) Instrucciones de montaje
- (PT) Instruções de montagem
- (CZ) Montážní návod
- (BA) Uputstvo za montažu


- (HR) Upute za montažu
- (HU) Szerelési útmutató
- (LT) Montavimo instrukcija
- (LV) Mont žas instrukcija
- (PL) Instrukcja montażowa
- (RO) Instrucțiuni de montare
- (SK) Návod na montáž
- (RU) Инструкция по монтажу
- (BG) Инструкции за монтаж
- (GR) Οδηγίες χώνευσης
- (SI) Navodilo za montažo
- (EE) Paigaldusjuhised
- (IS) Leiðbeiningar

**quadro evo
compartmentalized
solution**




W	W1	H	H1	D
450	350			400
700	600	1900	1800	600
900	800	2100	2000	600
1000	600			800


UCBS18FB
UCBC20FB





SX →






→









DX




UCBS18FB
UCBC20FB




UCBS18FB
UCBC20FB




H 1200 CHASSIS



H 1500 CHASSIS





H 1400 CHASSIS




H 1700 CHASSIS









**UCBS18FB
UCBC20FB**









**UCBS60FU
UCBS80FU**



UC500FU
UC700FU




UCBS60BB
UCBS80BB





PE-Bars

Please refer to the technical manual for quantities and positioning





Main connection



Please refer to the technical manual for quantities and positioning




UCBS12CH
UCBS14CH
UCBS15CH
UCBS17CH




UCBS12CH
UCBS14CH
UCBS15CH
UCBS17CH





UCBS12CH
UCBS14CH
UCBS15CH
UCBS17CH



UCxx60BL
UCxx80BL





UCxx60BL
UCxx80BL




UC500FU
UC700FU

UCBS60FUH
UCBS80FUH




UC500FU
UC700FU

UCBS60FUH
UCBS80FUH



UCBS3515CC
UCBS3517CC
UCBS3518CC
UCBS3520CC



UCBS3512FC
UCBS3514FC
UCBS3515FC
UCBS3517FC

