






GB JK04TK
JK06TK

Notice d'instructions
User instructions
Bedienungsanleitung
Instrucciones de uso
Instruções
Bruksanvisning
Gebruiksaanwijzing

ZD0748 - Issue 2




JK04TK - 4" (100mm) trunking kit
JK06TK - 6" (150mm) trunking kit




ZD0748 - Issue 2


Connect adapter plate(s) to required end(s)





Offer up trunking to adapter plate




Attach an end plate into place if trunking is not attached to both ends of trunking kit.




Fit trunking kit lid using joining bracket and attach trunking to adapter plate.



JK04TC
JK06TC



JK04TJ
JK06TJ



JK04TE
JK06TE



JK04TL
JK06TL



Scan with your smartphone QR scanner to go straight to the installation video. Or visit www.hager.co.uk/youtube