




6M 5017.c




MZ527N

- (FR) Signal défaut
- (GB) Signal contact
- (DE) Signalkontakt
- (IT) Segnalazione guasto
- (ES) Señal de defecto
- (NL) Foutmeldingscontact

- Notice d'instructions
- User instructions
- Bedienungsanleitung
- Istruzioni d'impiego
- Instrucciones de uso
- Gebruiksaanwijzing









Test **A**



Test **B**



Reset



Reset

