






- ⓁⒹ Montageanleitung
- ⓁⒻⒼ Notice d'instructions
- ⓁⒼⓅ Mounting instructions
- ⓁⒽ Istruzioni di montaggio

uniway UW-ST







- ⓁⒹ Schienentrennstück
- ⓁⒻⒼ Séparateur de barres
- ⓁⒼⓅ Busbar divider
- ⓁⒽ Separatore barra








● SL (M = max. 1.2 Nm)



M6







Hauptsitz

Hager AG
Sedelstrasse 2
CH-6020 Emmenbrücke
Tel. +41 41 269 90 00

Verkaufsniederlassungen

Hager AG
Glattalstrasse 521
CH-8153 Rümlang
Tel. +41 44 817 71 71

Hager AG
Ey 25
CH-3063 Ittigen-Bern
Tel. +41 31 925 30 00

Hager AG
Chemin du Petit-Flon 31
CH-1052 Le Mont-sur-Lausanne
Tel. +41 21 644 37 00

hager.ch
infoch@hager.com