User Instructions

Warranty

For details of the warranty on hager products, please refer to our terms and conditions.

The warranty is withdraw if:
After inspection by hager quality control dept the device is
found to have been installed in a manner which is contrary
to IEE wiring regulations and accepted practice
within the industry at the time of installation.
An explanation of defect must be included when returning

:hager

Front

TV & Satellite

Specifications

- Compliance: BS 3041 for TV outlet,

BS EN 50083 - 2 for Satellite outlet

Mounting instruction

- Remove screws and screwcaps 6. Press screwcaps to the holes from back of product. after screwed tightly.
- Remove screws holding cable clamp.
- 3. Remove the screw and insert cables. (WMSAT, WMTVF, WMTVM)
- 4. Connect cables ensuring all connections are both mechanically and electrically sound.
- Attach TV/Satellite product to wall box.
- 7. Installation should only be performed by a competent electrician and comply with the local wiring regulations in force at the time of
- 8. Suitable for standard box depth ≥35mm

WIS0064C10

folded line **Back**

Note:

1. Size:140(length)x70(width)

2. White background and black text

3. Paper:105g coated paper

Matiere / Werkstoff		Code	Épaisseur / Dicke	Volume / Volum	nen Ind	N' OC-OM/Pf-Nr.	Date/Datum	Nom/Nam
105g coated paper	,				cm3			
Traitement / Behandlung		Code	Codification Solly	Cotes sans tolerar specification N Maβe 0. Toleran DIN /		N 9G9019.00 L	' 9G9019.00 Unüberschreibares MaB	
Dessine par / Gezeichnet Heidi	Date / Datum April.28,2011	Bezeichnung:						
Controlê par / Gepruft "	Date / Datum	Désignation: Sollysta instruction sheet for TV & Satellite						
hager	Échelle/MaBsţab 1:1	Nr. WIS0064C10			Samples	Re	v:A	
m m mm 2) m m	Format A4	Ersatz fur " Remplace			 '''-	·		
HuiZhou hager Electric Ltd.		Ce dessin est la propriete de la soc iete "HAGER.II ne peut etre réproduit ou communique sans son autorisation .						