



## :hager



HYW007H 3P-HYW008H 4P HYW001H 3P-HYW002H 4P












The maintenance is necessary only for the aluminium wire connection: Tighten the screw 1 month after installation and then 3 months later tighten again.









The maintenance is necessary only for the aluminium wire connection:

Tighten the screw 1 month after installation and then 3 months later tighten again.