

info pilot lamp Order-No. : 2949

Operation- and Assembly Instructions

1 Safety instructions


Electrical equipment may only be installed and fitted by electrically skilled persons.

Always disconnect device before working on it. At the same time, take into account all circuit breakers that supply dangerous voltage to the device.

Failure to observe the instructions may cause damage to the device and result in fire and other hazards.

These instructions are an integral part of the product, and must remain with the end customer.

2 Device components



picture 1: Device components

- (1) Information light signal top
- (2) Frame
- (3) Insert

3 Function

Intended purpose

- Power supply for information light signal top
- Installation in appliance box to DIN 49073.
- Observe the technical data.



4 Information for qualified electricians

4.1 Fitting and electrical connection

Connecting and mounting the device



DANGER!

Electrical shock when live parts are touched. Electrical shocks can be fatal. Before carrying out work on the device or load, disengage all the corresponding circuit breakers. Cover up live parts in the working environment.

- Connect the insert. L: live N: neutral
- Mount the insert (3) in the appliance box (picture 1).
- Attach the frame (2) and the top (1).

5 Appendix

5.1 Technical data

Rated voltage	AC 230 V ~
Mains frequency	50 Hz
Connected load	0.8 W
Connection Single stranded	max. 4 mm ²

5.2 Accessories

cover for info pilot lamp

5.3 Warranty

We reserve the right to make technical and formal changes to the product in the interest of technical progress.

Our products are under guarantee within the scope of the statutory provisions.

If you have a warranty claim, please contact the point of sale or ship the device postage free with a description of the fault to the appropriate regional representative.

Berker GmbH & Co. KG

Klagebach 38 58579 Schalksmühle/Germanv Telefon + 49 (0) 2355/905-0 Telefax + 49 (0) 2355/905-111 www.berker.de

Order-No. 1345..